## **ECA** Manual


The programming manual is the same as original remote control. If our manual is not clear, you can search manual in google, youtube.also can contact us via Email. Anyway, we will try our best to make best service for you.

## Below is the programming manual

- 1. Remove the jumper "Clear" in the receiver and the LED light will turn on.
- 2. Choose, press and release the button on the new remote control, which you would like to operate

the receiver, for a period of five second.

- 4. Return the "Clear" jumper to its place.
- 5. Repeat steps 1-4 for teaching more remote controls.



WT Jumper