## **Cardin receiver without digit screen Manual**

The programming manual is the same as original remote control. If our manual is not clear, you can search manual in google, youtube.also can contact us via Email. Anyway, we will try our best to make best service for you.

## Below is the programming manual



- 1. Open the casing of your receiver. It is located next to your motor.
- On the receiver circuit board (diagram above), press the programming button (MEMO). Keep it pressed down. The LED light of the receiver blinks.
- While keeping pressed down the button MEMO, press the button you wish to program on your new remote control until the LED light of the receiver turns off.
- 4. Let the buttons go.
- 5. The LED light of the receiver blinks.
- 6. Press the button on your new remote control again. Let it go.
- 7. The LED light of the receiver turns off.
- 8. Repeat this procedure for each button you wish to program.
- 9. Wait 10 seconds.
- Your new remote control is programmed.