


GIBIDI Manual

The programming manual is the same as original remote control. If our manual is not clear, you can search manual in google, youtube.also can contact us via Email. Anyway, we will try our best to make best service for you.

HOW TO PROGRAMME YOUR REMOTE



Method for registering your new remote:

- 1- Open the casing of the radio receiver (located at the end of the wire from the antenna)
- 2- Press the programming button located on the radio receiver. Depending on the model, the button could be labelled: ENR or MEMO or PROG or REC, etc.

Note: On certain receivers, you only have to depress the programming button once and then release it. On others, you have to hold the programming button down.

- 3- A light on the receiver will light up, or flash.
- 4- Hold down the button on your new remote for one second.
- 5- Release the button: depending on the model, the light on the receiver will either go out immediately, or within 10 seconds.
- 6- Verify that your new remote is working correctly.
- 7- Close the casing of the receiver.