


Kinggates Manual

The programming manual is the same as original remote control. If our manual is not clear, you can search manual in google, youtube.also can contact us via Email. Anyway, we will try our best to make best service for you.

Below is the programming manual

Programmation à partir du récepteur :



1. Press the programming button P1 on the receiver board (press once for channel 1). Release the button. The LED L1 lights up.
2. Within the next 5 seconds, press the button on the new remote you wish to program. The LED L1 flashes once.
3. Wait for 10 seconds.
4. The button is now programmed.
5. Repeat steps to program the second channel. This time you press the programming button P1 twice.