NOVA Manual

The programming manual is the same as original remote control. If our manual is not clear, you can search manual in google, youtube.also can contact us via Email. Anyway, we will try our best to make best service for you.

Learning the transmitter(s) for pulsed operation:

- Open the receiver unit, and with power on, bridge the learn/J1 pins with the jumper provided.
- The red LED will now illuminate.
- Press the required button on the NOVA transmitter. The red LED will flash once, indicating that the transmitter button has been learned.
 - If you need to learn further buttons or `nitters, repeat the procedure as in Step 3.
- Once the LED has confirmed that the transmitter button has been learned, remove the jumper from the learn/J1 pins and store on one of the pins.
- Your transmitter will now activate the receiver, and your system is ready for use.



IMPORTANT NOTICE: When learning a transmitter into a multichannel NOVA receiver, the transmitter button can only be learned if the button number matches the channel number of the receiver, i.e. button one of a transmitter (single or multi-button) can only be learned to operate channel one of a receiver. Similarly button two of a multi-button transmitter can only be learned to operate channel two of a receiver, etc.